
ST & FM Roller Installation Instructions



Push hand wheel onto hub ensuring they lock in. Insert Hub through roller frame

Insert small circlip into the small shaft protruding through the roller frame and remove small screw and replace with plastic handle.

3Place small black plastic cover over the

tubes penetrating the frames. The cover

with the hole goes over the handle

Clip on plastic feet or on FM models only screw in wheels making sure the wheel with the brake is at the rear of

the roller

5

Connect the straps to the roller tube by removing the small black plugs

Use the alligator clips to attach to the blanket and adjust length as required

6

<u>ALWAYS</u> use the white over cover when the blanket is wound on the roller as failing to do so may void your warranty.

Extra straps are provided to lock over cover on when coving the blanket



Head Office

62 Parkhurst Drive Knoxfield VIC 3180 Telephone: 03 9887 2131

New South Wales

2/20-22 Foundry Road Seven Hills NSW 2147 Telephone: 02 9838 0000

Queensland

Factory 1, 8 Reichert Street Molendinar QLD 4214 Telephone: 07 5679 6821